

STIK-GARD



HONDA RANCHER-420
H-SG-420



INSTALLATION

Remove all of the plastic guards (2 per side). You will not need the hardware. Start by mounting the aluminum tab to the stick guard with the shortest bolt and nylock as shown on picture on right. Now locate the two M6 x 25 (longest bolts) Stick them thru the bottom of the guard thru the dimple add a spacer on the inside of the SG over the bolt and place the SG in position. Align the SG on the bottom of the a-arm until you can screw the bolt in the welded nut, hand tight only. One clamp will have a corner cut off, install it on the right side SG (shown). Install the other clamp then tighten all bolts starting with the clamp bolts first then the dimple bolt last. Repeat for the other side.

DO NOT OVERTIGHTEN

THANK YOU FOR PURCHASING OUR PRODUCT
ENJOY YOUR RIDE.

WWW.ALUMINUMPRODUCTS.COM