

## SKID-PLATE



HONDA RANCHER-420  
H-SP-420  
H-SPHH-420

## SKID-PLATE-HOOK-HOLSTER



## INSTALLATION

### INSTALL ALL NUTS & BOLTS HAND TIGHT FIRST

Remove plastic skid plate. You will not need hardware. Place Aluminum Products Skid Plate (SP) in position. Install the (2) M6x25mm (LONGEST) bolts into the bottom two holes hand tight only. Install the (2) M6x16mm (SHORTEST) bolts thru the top two holes, on the inside place two flat washers over bolts then screw on nuts. Now you can tighten all bolts and bolts/nuts.

THANK YOU FOR PURCHASING OUR  
PRODUCTS

**ENJOY YOUR RIDE!**

