

FULL BELLY SKID PLATE



PRODUCT INFORMATION

AND

INSTALLATION

POLARIS RZR 800 P-FBSP-RZR-800

Remove stock plastic skid. Keep large washers and screws, you will use them again.

Bolt together the two Full Belly Skid Plates on flat surface with bends up. Use ¼ x 1 bolts/washers/nuts provided, 2 washers per bolt each side. Tighten all 5 bolts/nuts.

Position FBSP and start in any hole the large washers/screws removed earlier, 14 total.

Place 3/8 x 1 bolt through front hole and through the hole in the steel front frame plate, inside install flat washer and nut. **DO NOT TIGHTEN AT THIS POINT.** When all flat washers are centered in holes on aluminum Full Belly Skid Plate you can tighten all bolts/nuts/screws. You will have 2 extra washers/screws.

Note: On the 2009 and up RZR it will be necessary to drill out the front hole with a 3/8" drill bit in order to install the front bolt. It is a tight fit but it can be done. This is important because this bolt prevents the FBSP from shearing off the smaller bolts that hold the FBSP in place. A frame brace added by Polaris covers the hole inside the frame, it is well worth the trouble of drilling that hole. You will not use the flat washer with the bolt, just the lock nut.

DO NOT OVER TIGHTEN BOLTS
THANK YOU FOR PURCHASING OUR PRODUCT.
ENJOY YOUR RIDE.