

SIDE SKIDS



POLARIS RZR 800
P-SS-RZR-800

PRODUCT INFORMATION

AND

INSTALLATION

If you purchased the FBSP-Set, install the FBSP first. Remove the 8 screws (if any) holding side plastic under frame. You will not use these screws again. Install 8 - 1/8" thick aluminum spacer washers over the 3/8" holes inside both side skids (side with labels). Hold them in place using narrow strips of duct tape. On the passenger side skid only, install 1 - 3/16" thick aluminum spacer washer on the one remaining 3/8" hole midway in skid. Place passenger skid in position, install the 4 long bolts/nuts on front and back ends hand tight. Repeat for driver's side. There are 1" access holes near the ends that allow nut to reach bolt. Use open end wrench with duct tape on one side to hold nut in place. Turn long bolts by hand until all 8 nuts are started. Using a flashlight see if the 8 frame holes along the outer edge have any threads, if so then use the bolts/washers (9) in small packet (in big packet) in 5 holes on passenger side, 4 holes on drivers side. **If there are no threads** you will use one m6x25 metric bolt in the middle hole in passenger skid then use 8 thread forming bolts in side holes on passenger side and drivers side. Using only a 1/4" drive ratchet, tighten the 2 rows of bolts plus the one bolt on passenger side. (DO NOT OVERTIGHTEN). You can now tighten the 8 long bolts/nuts.

DO NOT OVERTIGHTEN

THANK YOU FOR PURCHASING OUR PRODUCT.
ENJOY YOUR RIDE.

WWW.ALUMINUMPRODUCTS.COM

800-848-7225